

Antennas and Cables

Sebastian Büttrich, wire.less.dk
edit: September 2009, Pokhara, Nepal

Shortened version of

http://www.itrainonline.org/itrainonline/mmtk/wireless_en/08_Antennas_Cables/08_en_mmtk_wireless_antennas-cables_slides.odp

(edited by Alberto Escudero Pascal)

<http://creativecommons.org/licenses/by-nc-sa/3.0/>


Goals

- Focus on explaining the factors in the link budget equation
- Introduce a set of types of antennas and cables
- How to make the right choices
 - Optimal Service Area
 - Minimizing Interference
 - Best use of the radio spectrum

Table of Contents

- Review of Link Budget
- Introduction to Antennas
- Types of Antennas
- Polarization
- Cables and Connectors

Review of Link Budget



- A radio link has active and passive elements
- Antennas and Cables are **passive** elements

Review of Link Budget

- Passive elements
 - Absorb energy or focus the electromagnetic energy (beam)
 - Never supply more energy than they absorb
- Link Budget
 - $\text{Margin} = P(\text{tx}) - \text{Cable loss}(\text{tx}) + \text{Antenna Gain}(\text{tx}) - \text{FSPL} + \text{Antenna Gain}(\text{rx}) - \text{Cable Loss}(\text{rx}) - \text{Sensitivity}(\text{rx})$

Antenna Definition

- A passive device used to transform an RF signal
- Transformation from signal in cable to signal in free space – and back

Antenna Gain

- Antennas are passive elements that **do not amplify** the radio power
- Antennas target the signal in certain direction, but make it weaker in others (!)
- The antenna gain is a positive value to the link budget


Antenna Gain

- Compares the power sent by the antenna in a certain direction with the “Isotropic Antenna”.
- Given in isotropic decibels [dBi]
- Isotropic antenna
 - a hypothetical antenna that radiates or receives equally in all directions
 - a theoretical reference used as a way to express directional properties of physical antennas.

Radiation Pattern

- A graphical representation of the “shape” of the radio beam.
- Beam width: The area where 90% of the energy is focused.

Radiation Pattern




Source: <http://www.its.bldrdoc.gov/projects/devglossary/images/beamwi4c.gif>

Radiation Pattern

- Normalized dB scale
 - 0 dB: Direction of maximum gain of the antenna.
 - -3 dB: Angle where the antenna performs 50%.
 - The 3 dB beam width is normally known as service area/volume

Radiation Pattern: Example

- Typical Radiation Pattern of Sector Antenna
- 3 dB V-Beamwidth is 20° vertical and 90° horizontal



Omnidirectional Antenna

- 360-degree RF radiation pattern.





- Normally vertically polarized E-field.
- Normally low gain around 3 - 7 dBi.

Omnidirectional Antenna


- Best suitable for a wide service area with short links
- **Be very careful when using Omni antennas**
 - Consider potential problems with hidden nodes
 - Consider potential problems with interference
 - Consider narrow vertical pattern!!!

Omnidirectional Antenna



Omnidirectional Antenna

- If trying to maximize the service “area”, you might have problems with nodes very close to the antenna




Sectoral Antenna


- Used in Access Points (gateways/hubs) to serve Point-to-Multi-Point (PtMP) links.
- Normally vertically polarized but horizontally polarized are also available
- Typical gain of 6-13 dBi

Sectoral Antenna

- Good for serving a large area with a high density of connections
- Horizontal beamwidth to about 30-120°



Azimuth (H-field) radiation
pattern



Elevation (E-field) radiation
pattern

Sectoral Antenna



- A sectorial antenna with high gain needs careful mounting with respect to down-tilting

Sectoral Antenna

- Why do we need to sectorize?
 - Allows for multiple access points in one tower. More total bandwidth.
 - Able to isolate areas with higher levels of RF noise
 - Be able to separate short from long distance links (stability)

Directive Antenna

- Parabolic Antenna
- High Gain Patch / Panel Antennas
- Wave Guide Antenna (Circular: The famous Cantenna)
- Biquads





Parabolic Antenna



- Grid or closed surface
- Horizontally or Vertically Polarized

Parabolic Antenna

- Gain vs Beamwidth: 19 dBi vs 24 dBi
- Cartesian Radiation Pattern




Build Your Own Antenna

- Good quality and low cost antennas can be made mostly using common household goods
- Most suited: Cantennas, Biquads, Omnis (more difficult)
- Guides can be found many places on the net, e.g. at <http://wirelessU.org> and <http://wireless.ictp.it/handbook/download.html>

Build Your Own Antenna




- Cantenna



Build Your Own Antenna


- BiQuad

Simple 2.4GHz Antenna



Build Your Own Antenna

- BiQuad



Antenna Polarization

- WiFi Antennas are built to make radio signals propagate vertical and horizontal planes
- Polarization expresses the orientation of the waves electric field
 - If the E-field is horizontal, than the antenna is Horizontally Polarized
 - If the E-field is vertical, than the antenna is Vertically Polarized

Antenna Polarization

- Polarization is used to:
 - Increase isolation of unwanted signals source and hence reduce interference
 - Define different coverage areas by reusing frequencies

Antenna Polarization

- Antennas of the same radio link **MUST** use the same polarization
- Cross Polarization
 - The extra attenuation when one antenna is H and the other is V can be as big as 30 dB!

-

Antenna Polarization

- Using Several Parabolic Antennas on the same mast
- Cross Polarization
- Source www.radioscanner.ru



Cables and RF Signals

- Low loss coaxial cables connects radio transceiver to antenna
- With RF frequencies, the cable no longer behaves like a regular traditional wire.
- Cables with RF are **transmission line**.
 - Think in another antenna, radiation
- Impedance is a measurement of resistance to a current in a transmission medium

Cables and RF Signals

- Impedance remains constant with independence of the cable length
- Maximum transfer of energy between the transceiver and the antenna only takes place when all the circuit elements match the same impedance


Cables and RF Signals

- In data communication equipment (including WiFi) the impedance is always 50Ω (Ohm)
- If not, the radio signal (energy) will reflect back into the transmitter rather than into the antenna

Energy Loss in Cables

- The coaxial cable introduces a signal loss between the antenna and the transceiver.
- The signal is attenuated towards the antenna and the signal collected by the antenna is attenuated on its way back to the receiver.
- Typical cable loss for WiFi-friendly cables: 0.07 – 0.22 dB/m (but can be more!)

Energy Loss in the cables



<i>Cable type</i>	<i>Loss [db/100m]</i>
RG 58	ca 80-100
RG 213	ca 50
LMR-200	50
LMR-400	22
Aircom plus	22
LMR-600	14
1/2" Flexline	12
7/8" Flexline	6,6
C2FCP	21
Heliax 1/2 "	12
Heliax 7/8"	7

Energy Loss in the cables

- When you choose a cable you need to consider several factors:
 - How long cable do you need?
 - Do you need to bend the cable in sharp angles?
 - Do you need to transport/bring the cable from overseas?

Connectors



MC-Card



MMCX



RP-MMCX



U.FL



SMA Male



RPSMA Male



SMA Female



RPSMA Female



TNC Male



RPTNC Male



TNC Female



RPTNC Female



N-Male



N-Female

- Endless number of types
- Good connector: 0.1 dB
- Bad connector: several dB
- Invest in good connectors

Fig. Source: Connexwireless

Connectors

- Rule of thumb
 - Antennas and any other active elements, such as radios, normally have female connectors.
 - Cables do normally have male connectors.
 - The most common connector used for long cables is the N-type male




Fig. Source:
Solwise

Pigtail/Converter

- Pigtail matches two types of connectors
- Loss of 0.2-0.6 dB
- Small length cable patching
 - A radio with an antenna
 - A radio with a long run cable
- **Converter:** One unit with two types of connectors: 0.1 – 0.2 dB

Pigtail/Converter



Conclusions Antennas

- Antennas:
 - Start with Link Budget to see what you need in order to get enough margin
 - Be spectral efficient and follow the power regulations
 - Sectorize the access points, tilt antennas to match your coverage area

Conclusions Cables

- Cables

- Take care of your cables and connectors as they are always a point of failure.
- Microwave cables and specially connectors are precision-made parts.
- Be sure to know how much you can bend your chosen cable and never step over a connector!

Final Conclusions

- Good choices in equipment depends on your ability to understand radiation patterns, link budgets and the type of service that you aim for.



<http://creativecommons.org/licenses/by-nc-sa/3.0/>

Sources: this presentation from
<http://wirelessu.org>